



Key	No.	Size and Description	Usage
A	2	8-foot 3/4-inch clear pine 1 x 8	Cut to make five sides of the box and two cleats
B	1	4-foot 3/4-inch clear pine 1 x 8	Cut and routed into two braces
C	18	1 1/4-inch steel trim-head screws	Attach the back, bottom, front and sides of the box
D	4	3/8-inch steel trim-head screws	Attach the braces to the cleats
E	4	3-inch decking screws	Attach the cleats to the house
F	2	1 1/4-inch decking screws	Attach the box to the cleats

Notes: A circular saw can be used in place of the miter saw and table saw mentioned in steps 1 and 2. If your house has vinyl, aluminum or fiber-cement siding, prevent damage by boring screw-pilot holes before mounting the cleats.